

FA00382-EN

CE

Ρ

EN

CAME Connect for Security Systems



CLOUD CONNECTED TECHNOLOGY

User Manual

English

GENERAL INFORMATION

 $\label{eq:cameConnect} \mbox{ cameConnect is the technology that enables compatible CAME devices or systems to be controlled remotely.$

Once registered, owners can connect to their systems securely and manage operation remotely.

Registered users can remotely control a home automation system, a security control unit, manage openings and automation, view images recorded by the cameras in the CCTV system, answer video entry system calls etc... all using their smartphones or tablets.

CameConnect can be reached at the following URL: <u>http://www.cameconnect.net/</u>. In order to use the services offered by CameConnect, system owners must register on CAMEConnect.

Registering with CAMEConnect

roccipacio	
rossipaolo	
	6
	9
Paolo Ross	i
05/06/1968	1
Male	
rossipaolo@gmail.com (+39) 327 5749874
Via Giuseppe Verdi, 13, Fiume Veneto	, 33080 Province of
Via Giuseppe Verdi	13
Fiume Veneto	PN
Italy	33080
V I'm not a robot	e
I want to receive news and special of I agree with Privacy I agree with Terms and Conditions	reCAPTCHA Privato-Terra

This icon identifies the services dedicated to Private Users and directs to the registration window.

For home automation and security systems, however, there is no distinction between Private Users and Installer Users. The user that registers the system automatically has total control over permission to access the system and its features.

Choose your username and password carefully, because they will be the credentials required each time you access the CAMEConnect portal and the apps available for remote management.

After filling in all fields on the form, press the button 1 to finish the registration process.



A welcome message confirms registration and allows you to access the portal with your Private User credentials.

CAME CONNECT FOR SECURITY SYSTEMS

CAME Connect users can:

- Manage their profiles
- Register one or more systems on their own CAME Cloud space
- Enable remote control of the devices controlled by their systems
- Delegate the use of their devices to other CAMEConnect users
- Enable suitably trained users (qualified installers) to access their systems to perform maintenance, management or reprogramming

Profile management



The name of the logged-in user is always visible in the top right-hand corner of the portal. By clicking in this area, users can access profile configuration options or log out.

Username	Gender
rossipaolo	Male 🗸
First name	Last name
Paolo	Rossi
Birthdate	
5/6/1968	
Email address	Telephone number
rossipaolo@gmail.com	(+39) 347 8765432
Search your address	
Via Martiri della Libertà, 15, Dosso	n9 1
Via Martiri della Libertà	15
Casier	TV
Italia	31030
Password	Confirm password
Actually your technician is:	
Technician not set	

The window shows the profile data entered at the time of registration. This data can be changed at any time by the logged-on user.

• By filling in this field, the system geolocates the address and automatically completes the subsequent fields.

2 If you want to change your password, fill in these fields again. If the changes to the profile do not affect the password, the fields can be left empty.

3 Do not fill in (section reserved for enabling home automation system installers).

CAME Connect communicates with CAME devices or systems via the internet. Each type of system requires a device (gateway) that makes it possible to connect the system to the network.

For CAME security systems, the required gateway is 001SIGPRS - PXGPRS.

 \triangle Before proceeding, you need the identification code (keycode) printed on the gateway label.



Add a device using the menu on the left-hand side of the home page.

Registering a security gateway

C/		
		Home >> Devices management >> Add new device
۵	Home	ADD DEVICES
	Devices management	
	Devices list	+ Add GATEWAY
	Add new device	
0	Devices map	+ Add device
	Scenarios	
۵	Manage my sites	+ Add IpCam

GATEWAY PROPERTIES	
Key code	
3A22C089E10AA72B	2
Gateway name	
CP6099WL - Validazione GPRS	B
Description	
CP6099WL - Validazione GPRS	4
K Back + Sav	e

1 The button enables you to add a gateway to the list of paired devices managed by the user.

Fill in the gateway properties window as follows:

2 Enter the keycode on the label affixed to the gateway.

3 Choose a name to assign to the gateway for easy recognition.

4 Optional additional description.

Save the configuration and wait for the pop-up confirming successful gateway configuration.

Configuration options for the security gateway

	Home >> Devices management >> Devices lis	it (
🟦 Home	DEVICES	FILTER BY SITE No	SITE PHOTOS
III Devices management	CP6099WL - Validazione	GPRS	
Devices list	CP6099WL - Validazione GPRS	^{hn})	
Add new d		-	Search Q
Devices map			
Scenarios			
Manage my sites			
G Support requests			
♠ Events			

- Once registered, the gateway populates the list of registered devices.
- The device is working properly.
- The device is configured but not available (offline).
- When the 001SIGPRS/PXGPRS module is handling an incoming/outgoing voice call or sending a text message, it is temporarily offline.
 - 🗐 Security gateway, 📀 automation gateway, 🎓 home automation gateway.
- To access the configuration options, select the name of the newly-added device.
- 2 General information on the device and CAMEConnect registration status.
- 3 Name of the user who registered the gateway.

This user is automatically authorised to carry out any type of operation on the system: remote monitoring by means of the special app and reprogramming or configuration changes by means of the special software.

4 Back to the registered gateway list.

S Provides access to a list of events that have affected the device (errors, any service outages etc...).

6 Permanently removes the device from the list of those registered.



This area is a place for links to external documents useful for configuring or installing the device.

Delegating device access to other users

EW USER INVITATION	
Specify the email address of a new user and the	he services he will have access to.
If the specified email doesn't belong to an aire	eady registered user, the new user will be invited to register on CAME Connect.
User email:	
RVICES	
Remote control	
Enabling this service user will be able to remo	stely access the alarm/home automation system using Came Domotic Touch-
screen, Came Domotic Mobile or Came Domo	stic PC.
Available profiles:	
admin	
Always valid	
Valid from:	until:
Remote assistance	stoly changes the configuration of the home systematics system
Ensoning this service date will be sple to remo	nery change the configuration of the nome accontation system.
Service enabled	ų
Always valid	
Valid frame	
Valid from:	until:
Valid from:	until:
Valid from:	until:
Valid from: Alarm system programming Enabling this service user will be able to remo	until:
Valid from: Alarm system programming Enabling this service user will be able to remo	until:
Valid from: Alarm system programming Enabling this service user will be able to remo	until:
Valid from: Alarm system programming Enabling this service user will be able to remo Service enabled Always valid	until:
Valid from: Alarm system programming Enabling this service user will be able to remo Service enabled Always valid Valid from:	until:
Valid from:	until:

8 Enter the e-mail address of the user to whom you want to delegate system access. The user will receive an e-mail invitation to register on CAMEConnect. Once registered, the user will have access to the system with the privileges specified by the owner user.

9 This section allows you to delegate the user to manage all security system functions remotely (via the app) for a set time or indefinitely.

1 This section allows you to delegate the user to provide remote assistance (via Came D SW) and as a result change the security system configuration options for a set time or indefinitely.

1 This section allows you to delegate the user to provide remote assistance (via SWLink), change the security system configuration options and even reprogram it for a set time or indefinitely.

Save the configuration to add the user to the list of those allowed access.

It is possible to delegate user access in different ways. Generally, users actually using the system are allowed to remotely access the system for an unlimited time. Installer users or specialist technicians are allowed access for a set time, appropriate to the type of intervention to be carried out on the system.

In all cases the owner user has control over permission to access the system.

The form is only visible in the device list to the user that registered the device and not to users that have been delegated.

Page 7 - Manual code: FA00382-EN ver. 1 04/2016 © CAME s.p.a. - The data and information provided in this manual are subject to change at any time without prior notice.





Came S.p.A.

Via Martiri Della Libertà, 15 Via Cornia, 1/b - 1/c

31030 Dosson di Casier - Treviso - Italy 33079 Sesto al Reghena - Pordenone - Italy

1 (+39) 0422 4940 − 🔁 (+39) 0422 4941 **1** (+39) 0434 698111 − 🔁 (+39) 0434 698434

www.came.com